

Laboratory Freezers

TSG Series

Installation and Operation

334151H01 • Revision B • 07/01/2024



IMPORTANT Read this instruction manual. Failure to follow the instructions in this manual can result in damage to the unit, injury to operating personnel, and poor equipment performance.

CAUTION All internal adjustments and maintenance must be performed by qualified service personnel.

Material in this manual is for informational purposes only. The contents and the product it describes are subject to change without notice. Thermo Fisher Scientific makes no representations or warranties with respect to this manual. In no event shall Thermo be held liable for any damages, direct or incidental, arising from or related to the use of this manual.

© 2024 Thermo Fisher Scientific Inc. All rights reserved.

For your future reference and when contacting the factory, please have the following information readily available. It can be found on the data plate attached to your unit.

Model Number: _____

Serial Number: _____

The following information, if available, is helpful for contacting the factory.

Date Purchased: _____

Purchase order number: _____

Source of Purchase: _____

(manufacturer or specific agent/rep organization)

Contents

Model.....	1
Safety Information.....	2
Unpacking.....	4
Packing List	4
General Recommendations	5
Temperature Monitoring	5
Door Management	5
Intended Use.....	5
Initial Loading.....	5
Operating Standards	6
Unit Specifications	6
Installation.....	7
Location	7
Installation Instructions	7
Wiring	8
Shelves.....	9
Shelf Installation.....	9
Door Operation	9
Remote Alarm (Optional).....	10
Final Checks	11
Startup	12
Initial Startup.....	12
Product Loading and Unloading Guidelines	12

Operation	13
Control Panel	13
Standard Display	15
Navigation	15
Screens	17
Programming Mode	18
Temperature Settings	18
Direct Functions	18
Calibration (Parameters / cc to / cr)	20
Backup Battery	20
Temperature Monitoring	20
Alarms and Signals	21
Types of Alarms	21
Alarm Table	22
Maintenance	24
Cleaning the Cabinet Interior	24
Cleaning the Condenser Filter	24
Cleaning the Condenser	24
Automatic Defrost	24
Gasket Maintenance	25
Alarm Battery Maintenance.....	25
Preparation for Storage.....	25
Troubleshooting.....	26
End of Life Care	28
Warranty	29

Regulatory Compliance	30
Product Safety	30
Hydrocarbon Refrigerants.....	30
Electromagnetic Compatibility	30
Energy Efficiency.....	31
 IF YOU NEED ASSISTANCE:.....	 35

Model

The table below shows the units covered in this operation and installation manual by model number.

Table 1. Applicable Model

Model
TSG1225FA
TSG2325FA
TSG5025FA

Safety Information

In this manual, the following symbols and conventions are used:



This symbol when used alone indicates important operating instructions which reduce the risk of injury or poor performance of the unit.



WARNING: This symbol indicates potentially hazardous situations which, if not avoided, could result in serious injury or death.



WARNING: This symbol indicates situations where dangerous voltages exist and potential for electrical shock is present.



WARNING: This symbol indicates potentially hazardous situations, which if not avoided could result in fire.



CAUTION: This symbol, in the context of a CAUTION, indicates a potentially hazardous situation which if not avoided could result in minor to moderate injury or damage to the equipment.



CAUTION: This indicates a situation which may result in property damage.



This symbol indicates surfaces which may become hot during use and may cause a burn if touched with unprotected body parts.



CAUTION: Before installing, using or maintaining this product, please be sure to read the manual and product warning labels carefully. Failure to follow these instructions may cause the product to malfunction, which could result in injury or damage.



This symbol indicates possible pinch points which may cause personal injury.



The snowflake symbol indicates low temperatures and risk of frost bite. Do not touch bare metal or samples with unprotected body parts.



This symbol indicates a need to use gloves during indicated procedures. If performing decontamination procedures, use chemically resistant gloves. Use insulated gloves for handling samples.



This symbol indicates possible sharp points which may cause skin abrasion.

Below are important safety precautions that apply to this product.



CAUTION: Use this product only in the way described in the product literature and in this manual. Before using it, verify that this product is suitable for its intended use. If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.



CAUTION: Do not modify system components, especially the controller. Use OEM exact replacement equipment or parts. Before use, confirm that the product has not been altered in any way.



WARNING: Risk of Shock. Your unit must be properly grounded in conformity with national and local electrical codes. Do not connect the unit to overloaded power sources.



WARNING: Risk of Shock. Disconnect the unit from all power sources before cleaning, troubleshooting, or performing other maintenance on the product or its controls.



DANGER: Risk of Fire. This unit is not for storage of flammable materials.



DANGER: Risk of Fire. This unit is charged with hydrocarbon refrigerants. Only qualified service personnel should service this unit.



CAUTION: Unauthorized repair of your freezer will invalidate your warranty. Contact Technical Service at 1-800-438-4851 for additional information.



DANGER: No equipment that uses an open flame should be placed inside the freezer. This will harm the unit, hamper functionality and compromise your safety.



DANGER: Do not use any battery powered or externally-powered equipment in the freezer.



CAUTION: Risk of Abrasion. Use appropriate Personal Protective Equipment (such as gloves) while handling the drawers to avoid possible sharp points related injury.



WARNING: Ensure all ventilation openings are not obstructed.



WARNING: Do not use any mechanical devices or other means to accelerate the defrosting process.



WARNING: Do not damage the refrigerant circuit.



CAUTION: Do not use any accessory that requires modification (drilling, cutting, etc.) of the cabinet, door, or refrigeration system. Please contact Technical Support if you have any questions about accessories and compatibility.



WARNING: Cancer and Reproductive Harm
www.P65Warnings.ca.gov.

Unpacking

At the time of delivery, be sure to inspect the unit packaging for damage before signing for the shipment. If packaging damage is present, request immediate product inspection and file a claim with the carrier.

Note: Packaging damage does not denote that unit damage exists.

If concealed damage is found (damage that is not apparent until the item has been unpacked), stop further unpacking and save all packing for carrier inspection. Make a written request for inspection to delivering carrier. This must be done within 15 days after delivery. Then file a claim with the carrier.

Do not return goods to the manufacturer without written authorization.

Packing List

Inside the freezer cabinet is a bag containing:

- Essential safety instructions, including translated versions
- Certificate of Conformance
- Warranty Card
- Two cabinet door keys
- Small bag with shelving clips

If specified on the order, the bag may also include:

- QC temperature graph and test log
- Calibration information

Other items with your unit include:

- Power cord
- Anti-Tip Bracket Kit
- Shelves

Manual Label provides a link to the Installation and Operation Manual for the unit.

Note: To download the complete Installation and Operation Manual for the unit, please visit:

<https://www.thermofisher.com/usermanuals>

General Recommendations

This section includes some general recommendations for your unit.

Temperature Monitoring



IMPORTANT NOTE: We recommend the use of a redundant and independent temperature monitoring system so that the unit can be monitored continuously for performance commensurate with the value of product stored.

Door Management

When the door is open, the high temperature alarm is ignored for approximately 3 minutes (or the amount of time set by **Add** parameter in **Table 11**) to avoid false alarms. The service icon will flash to indicate the warning condition and the evaporator fan will stop while the door is open. The high temperature alarm delay may be adjusted if the high temperature alarm continues to activate when opening a door to load product. This will allow the unit time to recover to temperature for a set amount of time before alarming for high temperature.

When closing the door prior to the time set by Add parameter:

- Evaporator fan control resumes.
- The high temperature alarm is re-activated after the Add time lapses.

When the “High Temperature bypass” time has elapsed with the door open, the following events occur:

- The Open door alarm (dor) is signaled.
- Evaporator fan control resumes.

When closing the door after the time set by Add parameter:

- The Open door alarm (dor) ends.
- The high temperature alarm will end after the unit temperature is below the alarm threshold.

Intended Use

The freezers described in this manual are high performance units for professional use. These products are intended for use as cold storage of temperature sensitive materials such as media, reagents, clinical* and laboratory products.

Intended User(s): Expected users of this equipment include but are not limited to personnel from the following areas: professional and clinical* laboratories, Pharma and Biotech facilities, Academic, Industrial, and Government facilities or those trained in laboratory protocols put in place at your facility. The units are not for use by the general public.

*These products are not considered medical devices and have not been evaluated for use in environments or applications involving the diagnosis of diseases or other conditions, or in the cure, mitigation, treatment, or prevention of disease in man or other animals. These devices are not intended for the storage of samples to be re-introduced to the body (Examples: Blood and Blood Components, Tissues, Cells). These devices are not intended for use in classified hazardous locations, nor to be used for the storage of flammable or corrosive inventory.



CAUTION: Storage of unsealed corrosive substances may cause the interior of the unit to corrode.

Initial Loading

Allow the unit to operate at the desired temperature for a minimum of 24 hours before loading.

Load the unit one shelf at a time, starting from bottom to top shelf. After loading each shelf, allow the unit to recover to the desired set point before loading the next shelf. Repeat this process until the unit is fully loaded. Please refer to the section **Shelves** for shelf load ratings.



CAUTION: Failure to follow these procedures or overloading the unit may cause undue stress on the compressors or jeopardize user product safety.



CAUTION: All samples should be stored in a sealed container.

Operating Standards

The units described in this manual are classified for use as stationary equipment in a Pollution Degree 2 and Over voltage Category II environment.

These units are designed to operate under the following environmental conditions:

- Indoor use
- Altitude up to 2,000 m (6,512 ft).
- Maximum relative humidity 60% for temperatures from 15 °C to 32 °C (59 °F to 90 °F).
In high humidity ambient conditions, the door perimeter heater may need to be adjusted to avoid surface condensation. See **Table 11** for details.
- Main supply voltage fluctuations not to drop or exceed by 10% of the nominal voltage.
- Do not connect the unit to a GFCI (Ground Fault Circuit Interrupter) protected outlet as it may be subject to nuisance tripping.
- Do not use extension cords with this unit.

Other specifications are listed in the table below.

Unit Specifications

The data label is located on the upper left side of the unit.

See **Table 2** for specifications by model.

Always connect the unit to a dedicated (separate) circuit. Each unit is equipped with a service cord and plug designed to connect it to a power outlet which delivers the correct voltage.

Table 2. Unit Specifications

Model	Rated Voltage	Rated Current	Frequency / Phase	Power Module Plug	Unit Weight Kg (lbs)	Exterior Dimensions (D x W x H)
TSG1225FA	115 V	5.0 A	60 Hz/1		120 (265)	79.0 x 61.9 x 185.4 cm (31.1 x 24.0 x 73.0 in)
TSG2325FA	115 V	5.0 A	60 Hz/1	IEC C19	143 (315)	96.2 x 71.1 x 199.4 cm (37.9 x 28.0 x 78.5 in)
TSG5025FA	115 V	11.0 A	60 Hz/1		231 (510)	96.2 x 143.5 x 199.4 cm (37.9 x 56.5 x 78.5 in)

Installation



WARNING: Risk of Shock. Do not exceed the electrical rating printed on the data plate located on the upper left side of the unit.



CAUTION: Do not move the unit using the drain pan on the back. This could cause damage to the equipment.

Location

Install the unit on a level area free from vibration with a minimum of 6 inches of space on the sides and rear and 12 inches at the top. Do not position the equipment in direct sunlight or near heating diffusers, radiators, or other sources of heat.



WARNING: Risk of Injury. Do not move the unit while loaded. Move by pushing slowly at handle level or lower. Use caution on uneven surfaces.

Installation Instructions

The unit must be level both front to back and side to side when installed. If the unit is out of level, you may need to shim the corners or casters with thin sheets of metal. Be sure to set the brakes for units equipped with casters.



CAUTION: An unlevel unit may result in instability and performance issues for the doors.



WARNING: The freezer must be secured by the anti-tip bracket supplied. Unless properly installed, the freezer could tip when shelves are loaded. Injury and damage to the equipment and contents may result from the freezer tipping.

This freezer has been designed to meet all recognized industry tip standards for all normal conditions when anti-tip bracket is installed and properly engaged.

Anti-tip Bracket Installation instructions are provided for wood and concrete floors. Any other type of construction may require special installation techniques as deemed necessary to provide adequate fastening of the anti-tip bracket to the floor. For installation on floors other than wood and concrete, please contact technical support.

The use of this bracket does not prevent the tipping of the freezer when not properly installed.



Figure 1. Materials Supplied

Label	Description
1	Bracket
2	Bolts
3	Anchors
4	Instructions and Installation Template

Table 3. Tools Required

Wood Floor	Concrete Floor
	Flashlight
	Tape Measure
	1/2" (13 mm) Wrench
	3/4" (19 mm) Wrench
Drill	Hammer Drill
15/64" (6 mm) Drill Bit	1/2" (13 mm) Masonry Bit

1. Locating the Bracket

- Determine where you want the centerline of the freezer to be.
- Place the included template on the floor lined up with the centerline of the freezer and keep 6"-12" between the wall and the back of the unit.
- On the floor, mark the location of Hole #1 and Hole #2 (and Hole #3 and Hole #4 for double door units).

2. Anti-Tip Bracket Installation

Wood Construction

- Drill 15/64" (6 mm) pilot holes in locations marked in step 1.
- Place bracket on floor aligned with holes.
- Use supplied lag bolts to attach bracket to floor.

Concrete Construction

- Drill 1/2" (13 mm) holes in locations marked in step 1 with masonry bit.
- Slide lag screw anchors into holes to be flush with floor surface.
- Place bracket on floor aligned with holes.
- Use supplied lag bolts to attach bracket to floor.

3. Adjusting Bolt in Freezer

- Locate 1/2" bolt attached to bottom of cabinet.
- Unscrew 1/2" bolt until there is 1/2" clearance between floor and head of bolt as shown in the "Figure 2. Bolt Location".
- Tighten lock nut against bottom of unit.




Figure 2. Bolt Location

Label	Description
1	Back of Unit
2	1/2" Bolt Location
3	Detailed View
4	Lock Nut
5	1/2" Bolt
6	Floor
7	1/2" Clearance

4. Freezer Positioning

- Line up 1/2" bolt installed in step 3 with anti-tip bracket.
- Roll or slide freezer into position until bolt stops against bracket.
- Lock the casters.

5. Checking the Installation

Check to see if the anti-tip bracket is installed properly by shining light under cabinet and confirming bolt in cabinet is secured by bracket on floor.

Wiring

Wiring diagrams are attached on the back of the cabinet.



CAUTION: Connect the equipment to the correct power source. Incorrect voltage can result in severe damage to the equipment.



CAUTION: Risk of Shock. For personal safety and trouble-free operation, this unit must be properly grounded while in use. Failure to ground the equipment may cause personal injury or damage to the equipment. Always conform to the National Electrical Code and local codes. Do not connect the unit to overloaded power lines.



Do not position the unit in a way that impedes access to the disconnecting device or circuit breaker in the back of the unit.



Always connect the unit to a dedicated (separate) circuit. Each unit is equipped with a service cord and plug designed to connect it to a power outlet which delivers the correct voltage. Supply voltage must be within $\pm 10\%$ of the unit rated voltage. If cord becomes damaged, replace with a properly rated power supply cord.

Table 4. Power Cord Specification

Model	Power Cord Specifications
A	3-G 12 AWG, NEMA 5-15P, 15 A/125 V



CAUTION: Risk of Shock. Never cut the grounding prong from the service cord plug. If the prong is removed, the warranty is invalidated.



In an emergency, the power cord is a disconnect device.

Shelves

Single door laboratory freezers come standard with 4 full shelves and double door laboratory freezers come standard with 8 full shelves.

Maximum shelf capacity is 45 kg (100 lbs).

For safety in shipping, the shelves are packaged and secured inside the cabinet. Insert the shelf support hangers (included inside the unit) into the built-in shelf supports (located on the inside walls of the cabinet interior) at the desired locations. Position the shelves on the flat supports (Refer to **Figure 3**). Do not position shelving where it will disrupt the thermal bottle and probe assembly.




Figure 3. Shelf Support Hanger

Shelf Installation



WARNING: Do not move this unit while loaded.

1. Determine proper locations for shelf clips - the reference number on the pilaster can serve as a guide to ensure all clips are properly located and even.
2. Insert the top of the shelf clip into the desired hole of the pilaster - the retaining tab should be facing upwards.
3. Rotate the shelf clip downwards and insert the bottom tab into the appropriate hole in the pilaster. Note that the clip may need to be squeezed slightly during installation in order to fit.
4. Install shelves onto clips with the product retention bar facing upwards. Be careful not to dislodge clips during shelf installation.
5. Prior to loading the shelf, ensure that the shelf is resting on each of 4 clips and the clips are installed.



CAUTION: Improper shelf clip installation may cause shelf and/or product damage to the unit.



CAUTION: Do not overload the shelves, the unit is designed to utilize all shelves that are supplied in an equally spaced manner.

Door Operation

Laboratory freezers have swinging doors to allow access to cargo.



CAUTION: Door seal integrity is critical for unit's performance. Never route anything through the door seal. A loose fitting gasket allows moist air to be drawn into the cabinet, resulting in quicker frost buildup on the evaporator coil, longer running time, poor temperature maintenance, and increased operation cost.



WARNING: Risk of Fire. There are port holes in the walls of the cabinet to help facilitate routing of tubing, independent temperature sensors, and other non-electrical items. The ports are not intended to supply power to devices inside the device. Be sure to seal the holes after routing items to prevent undesired air exchange.

Swinging Doors

The doors on all swinging door units are designed to stay open if opened 90 degrees or more. The door spring tension cannot be adjusted. If the self-closing door does not work properly, make sure the unit is level.



CAUTION: Keep hands and body parts clear of closing doors. The moving parts create a potential pinch point.

Remote Alarm (Optional)

All units have factory-installed local alarm contacts that can be used for remote alarm systems. See the **Alarm Relay** column on **Table 14** for alarms that will trigger the remote alarm relay.

The maximum distance between a freezer and a remote alarm depends on the wire gauge used. Refer to the table below:

Remote alarm terminals are located at the rear of the machine compartment. The three terminals are: COMMON, OPEN ON FAIL (Normally Closed), and CLOSE ON FAIL (Normally Open).

Table 5. Remote Alarm

Wire Gauge	Total Wire Length (feet)	Distance to Alarm 1/2 Wire Length (feet)
20	530	265
18	840	420
16	1330	665
14	2120	1060
12	3370	1685

REMOTE ALARM CONNECTIONS CONNEXIONS DE L'ALARME À DISTANCE

CONTACT RATING:
MAX. VOLTAGE - 30V
MAX CURRENT - 2A LIMITING TO 60W/60VA

CARACTÉRISTIQUE DU CONTACT:
TENSION MAX. : - 30V
COURANT MAX. : 2A LIMITATION À 60 W/60 VA

WIRE COLOR (FIL DE COULEUR)	FUNCTION (FONCTION)
○ GREEN (VERT)	COMMON (COMMUNE)
○ BLACK (NOIR)	OPEN ON FAIL (EN POSITION OUVERTE)
○ RED (ROUGE)	CLOSE ON FAIL (EN POSITION FERMÉE)

To install the remote alarm, make the following connections:

1. Connect the COMMON terminal on the cabinet switch to the COMMON wire on the alarm.
2. To get an alarm when the switch contacts open, connect the OPEN ON FAIL terminal on the cabinet to the OPEN ON FAIL wire on the alarm.
 - a. To get an alarm when the switch contacts close, connect the CLOSE ON FAIL terminal on the cabinet to the CLOSE ON FAIL wire on the alarm. The COMMON and CLOSE ON FAIL wires must be tied together in this application.
3. Plug the alarm system service cord into an electrical outlet.

Final Checks

Before start up, be sure to complete the following steps:

1. Make sure that the unit is free of all wood or cardboard shipping materials, both inside and outside.
2. Check the positions of the shelves. If you want to adjust the positions, see instructions in **Shelves**.
3. Verify that the unit is connected to a dedicated circuit.

Startup

Initial Startup

To start up the freezer, complete the following steps:

1. Verify that the sensor probe(s) have been installed in the bottle(s).
2. Connect the AC mains power cord to the mains power inlet connector.
3. Ensure the double pole circuit breaker switch located next to the power inlet is in “OFF” position (i.e. “O” position).
4. Connect AC mains power cord to a wall outlet on a dedicated circuit.
5. Ensure the double pole circuit breaker switch located next to the power inlet is in “ON” position (i.e. “I” position).
6. The warm alarm will be delayed at initial startup for 90 minutes after unit is powered on. After 90 minutes has elapsed the warm alarm will function with no delay. If the unit has not reached below the warm alarm threshold 90 minutes after initial startup the unit may begin to alarm. Press the “Prg” button to silence this alarm. Please see **Operation** section for additional details.
7. Allow the unit to reach operating temperature before loading it with any product. To stabilize the temperature profile, a 24-hour waiting period is recommended.
8. If you have a remote alarm, hook it up at this point (Refer to **Remote Alarm (Optional)**).
9. If desired, lock the cabinet door using the key. Place duplicate key copies in a safe place.

All the controls should now be fully operational, and all the visual indicators active. Occasionally, batteries may discharge during storage or shipping - if you see a low battery alarm during initial startup, please allow 24 hours for the battery to recharge. If low battery alarm persists after 24 hours, please contact an authorized Service representative.

Product Loading and Unloading Guidelines

When loading your laboratory freezer, ensure to observe the following guidelines:

These are important to ensure that air can circulate properly and evenly distribute the temperature throughout the interior.

- Distribute the load as evenly as possible. Temperature uniformity depends on air circulation, which could be impeded if the internal storage components are overfilled, particularly at the top of the cabinet.
- For critical applications, be sure that the alarm systems are working and active before you load any product.
- Ensure clearance between the top of the cargo and the bottom of the shelf. Lack of clearance may affect unit performance.
- For initial product loading and after removing the shelves for cleaning, be sure to load the unit from the bottom Shelf up to ensure the components are seated properly.
- Avoid disrupting the thermal bottle(s) when repositioning interior components.
- The floor of the cabinet should not be loaded.
- Never load the unit above the load limit line.
- Do not load product cargo against the wall, cargo should not extend past shelf edge.




Figure 4. Load Limit Line

Operation

Control Panel




Figure 5. Control Panel

1. Display
2. Buttons
3. Icons

Table 6. Keypad

Button	Description	On/When Pressed	Flashing
	Minimum temperature	Direct access to minimum recorded temperature	-
	Reset minimum and maximum temperature	Reset minimum and maximum recorded temperatures (requires confirmation)	-
	Maximum temperature	Direct access to maximum recorded temperature	-
	Setpoint/Up arrow	Increase value Scroll menu / change setpoint	-
	Program	<p>Pressed briefly:</p> <ul style="list-style-type: none"> • Enter menu branch • Save value and return to the parameter code <p>Pressed and held (3 s):</p> <ul style="list-style-type: none"> • From standby, unlock keypad and enter programming mode • When scrolling, go to the previous parameter 	-
	Down arrow	Decrease value or scroll menu	-
	Compressor	Active	Awaiting
	Battery status	Charging	Needs replacement
	Temperature Alarm	Temperature alarms present	-
	°C	Unit of measure °C	-
	°F	Unit of measure °F	-
	Service Maintenance	Active alarms	-
	Battery Test	<p>Pressed briefly:</p> <ul style="list-style-type: none"> • Begin battery test 	Battery test starting
	Alarm Log	Logged alarm records present if pressed: access alarm log menu	-

Note: During navigation, the buttons will be on/flashing only if enabled.

Standard Display

At start-up, the user terminal briefly shows the firmware version and then the standard display. The standard display will show:

- All units will display the temperature reported by the independent weighted temperature probe.
- Note that the controller does not display any decimals when reporting temperature, and the values displayed are not rounded, but are truncated. Therefore, if the display is showing a temperature of 24 °C, the actual value could range from 24.0 °C to 24.9 °C.

Note: If there is an active alarm, press any button to mute the buzzer. If alarm is still active after 30 minutes, the buzzer will re-activate.

Display Active Functions and Direct Access of Functions

When pressing any button, the display shows the message “Loc” and the icons corresponding to the currently active functions come on to indicate the status of the unit. On pressing PRG for 3 s, the display shows 3 dashes in sequence and enters direct access mode.

In this mode:

- The buttons that are on steady indicate that the corresponding function is active, press the button to deactivate it or access the function;
- The buttons that are flashing indicate that the function is not active and can be activated by pressing the button; When pressing the button, the display shows information on the status of the selected function (On/Off).

Note: If no button is pressed, after 7 seconds the terminal will automatically return to the standard display.

Table 7. Direct Access Icons on User Terminal

Icon	Action in Direct Access Mode
	Direct access to minimum temperature
	Reset minimum and maximum temperatures
	Direct access to maximum temperature
	Direct access to setpoint
	Perform battery test
	Direct access to alarm log

Navigation

To navigate the menu tree, use the following buttons:

- UP and DOWN to navigate the menu and set the values;
- PRG to enter the menu items and save the changes made;
- Select the menu item or ESC to return to the previous branch.


Example of how to set parameter St (set point):



1. Wait for the standard display to be shown;




2. Press PRG to enter display currently active functions;



3. Press and hold PRG for 3 seconds to access direct access mode. If you have set a password, you will see the “PSd” screen appear before entering direct access mode. Enter your password to continue to direct access mode. If you have not set a password or the password is 0, you will not see this screen and will go directly into direct access mode, indicated by three dashes on the screen;



4. Press PRG to enter programming mode; the UP and DOWN buttons will flash and the first category of parameters dir (=direct functions) will be displayed;



5. Press DOWN until reaching the parameter category Ctl (=control);



6. Press PRG to display the first menu item: St (=setpoint). Press PRG to display the parameter value;



7. Press UP/DOWN to modify the value;



8. Press PRG to save the setting and return to the menu

CAUTION: if the PRG button is not pressed, the new setting will not be saved;



9. Press UP/DOWN to select ESC and press PRG to return to the parameter categories;




10. Press DOWN to move to the next category and follow steps 6 to 9 to set the other parameters;



11. Once the settings have been made, to exit the categories select ESC and press PRG.



Note: If no button is pressed, after 20 seconds the terminal will automatically return to the standard display.



Screens

The possible states of the terminal are shown in the table below.

Table 8. Screens

Icon	Status	Description
	Standard	The display shows the main value, alternating with any alarms and signals
	Display active loads	The terminal shows any active loads, the keypad is locked
	Direct access mode	The loads can be activated or deactivated and the direct functions accessed from the keypad
	Programming menu	Scroll the programming menu using the arrow buttons
	Parameter programming/display values	Set the parameters using the arrow buttons or display read-only values
	Password entry	Enter password to access direct access mode (if password is not set, or set to "0")

Programming Mode

In direct access mode, pressing PRG enters programming mode, where the unit's main operating parameters can be set.

Notice: In the default settings, the user password is set to 0 and is not required when entering direct access mode; if the password has been set to a value other than 0, this needs to be entered to access direct access mode and programming mode.

The menu items available and parameters visible on the user terminal are listed below.

Table 9. Programming Menu

PSD	dir (Direct functions)	nnt	CtL (Control)	Pro (Temperature probes)	HcP (Temperature alarms)	CnF (Configuration)	ALn (Alarms)	ESC
	See the following table	rL2	St	/ 5	HAn	Hb	AH	
		rH2	rHU	/ cr	HFn	PDU	AL	
		rt	ESC	/ cc	rHP	ESC	Ad	
		ESC		ESC	ESC		Add	
							rSA	
							ESC	

Temperature Settings

The factory default temperature setting is -25 °C for all laboratory freezers. To change the factory settings, refer to programming instructions.

The freezer described in this manual is designed for optimum performance and alarm notifications at a setpoint of -25 °C. Changing setpoint or other parameters may impact the functions listed above. Please note that the compressor may need to run constantly in order to achieve setpoint in high ambient temperature settings (27 °C or warmer). If you notice that your compressor is not cycling, take steps to reduce ambient temperatures.



CAUTION: Changing the -25 °C factory setpoint could adversely affect the performance of your freezer. Make sure that you understand the product requirements before making any adjustments to the factory setpoint.

Direct Functions

Table 10. Direct Function Parameters

Acr.	Description
boF	Activate battery storage status
dFn	Start defrost
Fr	Firmware version
OnF	Unit ON/OFF
SAh	Display alarm log
Sd	Defrost probe
SPr	Product probe
SrG	Control probe

Table 11. Programming Parameters

Par.	Menu	Desc.	Def.	Min	Max	UOM
St	CtL	Temperature control setpoint	-25 / -13	-29 / -20.2	-15 / 5	°C / °F
rHU	CtL	Perimeter heater power	50	0	100	%
rSA	ALn	Reset alarms	0	0	1	-
AH	ALn	Relative high temperature alarm threshold	10 / 50	5 / 41	555 / 1031	Δ °C / °F
AL	ALn	Relative low temperature alarm threshold	10 / 50	5 / 41	200 / 392	Δ °C / °F
Ad	ALn	Delay time for high and low temp. alarms (AH,AL)	0	0	240	min
Add	ALn	High temperature alarm bypass time for door open	3	1	240	min
rH2	nnt	Maximum temperature value in the monitored period	-	-	-	-
rt	nnt	Monitoring period	-	-	-	-
HAn	HcP	Number of type HA alarms	0	0	6	-
HFn	HcP	Number of type HF alarms	0	0	6	-
rHP	HcP	Reset temperature alarm log	0	0	1	-
rL2	nnt	Minimum temperature value in the monitored period	-	-	-	°C / °F
Hb	CnF	Enable buzzer: 0 = disabled; 1 = enabled	1	0	1	-
PDU	CnF	User password	0	0	999	-
/ cc	Pro	Control Probe calibration offset	Varies by model	-20 / -4	20 / 68	Δ °C / °F
/ cr	Pro	Product Probe calibration offset	Varies by model	-20 / -4	20 / 68	Δ °C / °F
/ 5	Pro	Unit of measure: 0 = °C; 1 = °F	0	0	1	-

Calibration (Parameters / cc to / cr)


The controller offers the possibility to calibrate values read by the probes. In particular, parameters /cc to /cr are used to increase or decrease the values read by the probes connected to the analogue inputs, consistently with the unit of measure.

/ cc is the control probe calibration offset. The difference in temperature between the control probe value and the average compartment temperature that is used to control the cooling system to the unit setpoint during steady state operation. All units are provided with a factory default setting for optimal cooling control. This can be useful to adjust if there is a discrepancy between the unit setpoint and the average cabinet temperature.

/ cr is the product probe calibration parameter. The difference in temperature between the display probe value seen on the User Interface display and the average compartment temperature at the unit setpoint during steady state operation. All freezers are provided with a factory default setting for the display to provide accurate reading compared to the average cabinet temperature. This can be useful to adjust the display during unit calibration procedures.



CAUTION: This modification may not be allowed by site procedures as it alters the measured value. Verify that you have permission to make the modification.



- T1 Temperature read by the probe
- T2 Calibrated temperature
- A Calibration offset
- min, max Field of measurement

Backup Battery

The controller can manage an external backup battery. This ensures some minimum controller functions when no power is available, and signals anomalous operation in the event of a blackout. During normal operation, the controller recharges

the battery and performs a test every 24 hours to verify correct operation. The test can also be run manually by pressing the battery test button (see **Keypad**). Activation of the backup battery can be disabled when the unit is in storage using the boF parameter turned ON within the direct functions.

The following battery is supplied with the unit: Lead-acid VRLA, 6V, maximum discharge current 200 mA. Typical charging current is 30 mA (50 mA max).

The table below shows the operation of the user interface and the various devices in the event of a power failure:

Table 12.

Function	Behaviour with power failure
Display	The digits go off and only the decimal point remains flashing. Pressing PRG reactivates the standard display for the time bbd
Button backlighting (if present)	PRG button only
Icons	Service icon only flashing
Buzzer	Will be on during alarming and will silenced by pushing the program icon, after 30 minutes the buzzer will reactivate.
Relays	All disabled
Alarms	The power failure is signalled by alarm BLC, visible only by pressing PRG

Note: In the event of temperature alarms, these are signaled as normal, even in the event of a power failure.

Temperature Monitoring

The controller can record the minimum value rL and maximum value rH read by the product probe. The monitoring session can be reset at any time, after which the new maximum and minimum values are logged. Refer to **Table 7. Direct Access Icons on User Terminal** for more details.

Note that the controller does not display any decimals when reporting temperature, and the values displayed are not rounded, but are truncated. Therefore, if the display is showing a temperature of 24 °C, the actual value could range from 24.0 °C to 24.9 °C.

Alarms and Signals

Signals

Signals are messages shown on the display to notify the user of the control procedures in progress (e.g. defrost) or to confirm keypad input.

Table 13. Signals

Display code	Description
dEF	Defrost running
Loc	Display locked
Off	Switch OFF
On	Switch ON

Types of Alarms

The controller can display two types of malfunctions:

- **Warning**, when this type of error occurs, the alarm code is shown on the display, alternating with the main value, and the “Service” icon  is shown on the display, however the buzzer does not sound, no relay is activated; some signals fall under this category, e.g. defrost ended due to maximum time, temperature alarms, configuration errors.
- **Alarms**, when this type of error occurs, the alarm code is shown on the display, alternating with the main value, and the “Service” icon  comes on, the buzzer flashes and the relay is activated; this category includes alarms for which with the relay is configured as an alarm, probe errors, temperature alarms, frost protection, etc.

Both warnings and alarms can be reset automatically, manually or semi-automatically:


- **Automatic**, when the cause is no longer present, the alarm also ceases;
- **Manual**, when the cause is no longer present, the alarm remains active until manually reset by parameter;
- **Semi- Automatic**, reset is automatic 3 times in an hour, after which manual reset is required.

Active alarms are signaled by the buzzer (see parameter Hb) and the flashing of the “Service” icon . The alarm code is shown on the display, alternating with the main value. Pressing any button mutes the buzzer. If more than one error occurs, these are displayed in sequence. When an alarm is

cleared, it is stored in the alarm log containing a maximum of five alarms, in a FIFO list (the 6th alarm overwrites the 1st alarm, and so on). The error log can be accessed from the user terminal.

Example

Display after HI error.



Alarm Table

Table 14. Alarm Table

Display code	Log code	Description	Delay (default)	Icon display	Alarm relay	Buzzer	Reset	Effects on control
bAt	39	Battery faulty or not connected	-	YES	YES	YES	Automatic	-
bLC	40	Blackout in progress	-	YES	NO	YES	Automatic	No power to unit, controller power only
btS	41	Battery test in progress	-	NO	NO	NO	Automatic	-
CE	28	Configuration write error	-	NO	NO	NO	Automatic	-
dor	15	Door Open	1 min	YES	YES	YES	Automatic	See Door Management
E1	1	Probe 1 faulty or disconnected	-	NO	NO	NO	Automatic	According to the connected function
E2	2	Probe 2 faulty or disconnected	-	NO	NO	NO	Automatic	
E3	3	Probe 3 faulty or disconnected	-	NO	NO	NO	Automatic	
Ed1	10	Defrost terminated after maximum time	-	NO	NO	NO	Automatic	-
Etc	9	Clock error	-	NO	NO	NO	Manual	-
HA	21	Type HA temperature alarm (high temp. during operation)	-	NO	NO	NO	Manual	-
HF	22	Type HF temperature alarm (high temp. after blackout)	-	NO	NO	NO	Manual	-
HI	24	High temperature	Ad (0s)	YES	YES	YES	Automatic	-
LO	23	Low temperature	Ad (0s)	YES	YES	YES	Automatic	-
MAn	38	Output status overridden in manual mode	-	YES	YES	YES	Automatic	-

Table 14. Alarm Table

Display code	Log code	Description	Delay (default)	Icon display	Alarm relay	Buzzer	Reset	Effects on control
rE	12	Control probe faulty or disconnected	-	YES	YES	YES	Automatic	Compressor operation in duty setting mode (par. c4); dead band OFF
SF	27	Configuration not completed correctly	-	NO	NO	NO	Manual	-
SrC	35	Maintenance request	-	YES	YES	YES	Manual	-

Low and High Temperature Alarms LO and HI

Table 15. Low and High Temperature Alarm

Par.	Description	Def.	Min	Max	UOM	User	User terminal
AH	Relative high temperature alarm threshold	10 / 50	5 / 41	555 / 1031	°C / °F	U	YES
AL	Relative low temperature alarm threshold	10 / 50	5 / 41	200 / 392	°C / °F	U	YES

Maintenance



WARNING: Risk of Shock. Disconnect equipment from main power before attempting any maintenance to equipment or its controls unless stated otherwise.

Cleaning the Cabinet Interior

To clean the cabinet interior, remove any product or samples stored in the unit, then remove the shelves (Refer to **Shelves**). Use a solution of water and a mild detergent for cleaning. Rinse the interior storage components and wipe them dry with a soft cloth.

Compatible cleaning agents include the following: Mild detergent, Hydrogen Peroxide, Acetic Acid, Quaternary ammonium cleaning solutions, and 70% Isopropyl alcohol.

Cleaning the Condenser Filter

Clean the condenser filter every three months. There is one condenser filter located in the back cage of the unit that can be accessed without removing the back cage or disconnecting the power.

To clean the filter, complete the following steps:

1. Remove the filter by pulling upwards through the slot in the back cage.
2. Shake the filter to remove loose dust.
3. Rinse the filter in clean water.
4. Shake the excess water from the filter and let it dry.
5. Reinstall filter by pushing downwards through the slot in the back cage.



CAUTION: Risk of Abrasion. Do not pull the filter downwards from the bottom. The condenser has sharp surfaces.

Cleaning the Condenser



CAUTION: Condensers should be cleaned at least every six months; more often if the laboratory area is dusty. In heavy traffic areas, condensers load with dirt more quickly. Failure to keep the condenser clean can result in equipment warm-up or erratic temperatures.



CAUTION: Risk of Abrasion. Never clean around the condensers with your fingers. Some surfaces are sharp.

The condenser is located in the top rear of the machine compartment. To clean the condenser, complete the following steps:

1. Disconnect the power.
2. Remove the filter.
3. Vacuum the condenser and clean up any loose dust.
4. Replace the filter.
5. Reconnect power.

Automatic Defrost

The defrosting process on all TSG auto-defrost freezers initiates automatically in response to a built-in timer. The defrost timer will activate a defrost approximately every 5 or 7 hours depending on the model and will initiate at the end of a cooling cycle under normal conditions. During this time, there will be an increase in display temperature on the UI display and the compressor may operate at a louder volume than normal.

Under adverse conditions, the defrost may initiate before the end of a cooling cycle and prior to the 5 hour time. Defrost water is collected in a pan in the rear of the unit and evaporated using refrigeration system heat. No maintenance is required.

Gasket Maintenance

Periodically check the gaskets around the door for punctures or tears. Leaks are indicated by condensation or frost which forms at the point of gasket failure. Make sure that the cabinet is level (Refer to **Location** for leveling information).

Keep the door gaskets clean and frost free by wiping gently with a soft cloth.

To check the door seal, complete the following steps:

1. Open the door.
2. Insert a strip of paper (a couple of inches wide) between the door gasket and the cabinet flange and close the door.
3. Slowly pull the paper strip from the outside. You should feel some resistance.
4. Repeat this test at 4-inch intervals around the door. If the door does not seal properly, replace the gasket.

Alarm Battery Maintenance

Have a certified technician replace the alarm battery every twelve months at most or when the alarm is active. The part number for a replacement battery is 322533H02.

Preparation for Storage

If the unit is going to be stored in an off condition, allow the unit to warm up and dry out with the door open before moving into storage. Access the direct function and change boF to "On".

Note: Refer to **Operation** section for more details about preparing the battery for storage mode.

Troubleshooting



WARNING: Troubleshooting procedures involve working with high voltages which can cause injury or death. Troubleshooting should only be performed by Factory Authorized Service Personnel.

This section is a guide for troubleshooting equipment problems. Component parts must be replaced only with like components.

Table 16. Troubleshooting Procedure

Problem	Cause	Solution
Unit does not operate, Power Failure Indicator is on, or unit only displays a decimal point	Power supply or power failure	<p>Check that the cord is securely plugged in.</p> <p>Plug another appliance into the outlet to see if it is live.</p> <p>Check that the double pole circuit breaker located next to the power inlet is in “ON” position (i.e. “I” position). Try cycling the switch to OFF position (i.e. “O” position) and then bring to ON position (“I”).</p> <p>Test the voltage and verify that it is correct for your unit (Refer to Table 2).</p> <p>If the outlet is dead, check the circuit breaker or fuses.</p> <p>The unit should not be connected to a GFCI (Ground Fault Circuit Interrupter) protected outlet as it may be subject to nuisance tripping.</p>
Temperature too high	Control setting too high	<p>Reset control.</p> <p>If parameter settings have been changed but the unit is not reflecting changed parameters, it is recommended to power the controller off and on again to realign any timings in progress. Wait at least 5 seconds after changing the parameter settings before powering the controller off in order to allow the data to be correctly saved to the memory.</p>
Temperature fluctuates/ insufficient cooling	Inadequate air circulation	Improve air movement.
	Temperature control	Make sure that the control is set correctly.
	Condenser clogged	Make sure the condenser is clean.
The equipment makes too much noise	Other causes	If the temperature control is set correctly, the condenser is clean, but temperature continues to fluctuate, call an authorized service representative.
	The equipment is not level	Place the equipment on an even surface or use shims to adjust height at corners, refer to previous Installation section for instructions.

Table 16. Troubleshooting Procedure (Continued)

Problem	Cause	Solution
Unit warms up	Door is open	Make sure the door is completely closed.
	Door seal check	Check the door seal.
	Warm product recently loaded in unit	Allow ample time to recover from loading warm product.
	Power supply	Check for proper voltage to the unit. If there is no voltage to the unit, call an electrician.
	Setpoint is off	Adjust setpoint, refer to previous Temperature Settings in Operation section.
Unit noisy	Compressor not functioning	If the compressor is not running and the power failure alarm is on, have an electrician check for proper voltage to the unit. If the compressor is not running and the power failure alarm is off, call the customer service for assistance.
	Extended air leak into freezer	Warm air entering the freezer from extended door openings, leaking gaskets, or unsealed port holes may create excess frost and ice buildup in the freezer that the automatic defrost may not be able to remove. This will inhibit freezer cooling. The freezer needs to be manually defrosted by turning off the unit to allow all frost and ice to melt.
Unit noisy	Loose parts or mountings	Contact Technical Support.
Condensation around door frame	Gaps exist in unit port holes	Ensure all port holes in the cabinet top, sides, and back are sealed properly to prevent warm airflow into the cabinet. Seal any gaps.
	Door seal is broken	Verify nothing is placed through the door seal such as a sensor. Check the door seal. Refer to the instructions in Section Gasket Maintenance .
	High humidity conditions	Increase perimeter heater power per Table 11 .
Compressor is running constantly, not cycling	High ambient temperature	Take steps to reduce ambient temperature.
Unit is warm around door frame	Perimeter heater is on	This is a normal function of the unit and is a result of the perimeter heater to reduce condensation.

End of Life Care

Some considerations and suggestions are listed below for proper disposal of this product. While addressing these actions for safe recycling and disposal, please follow all guidelines, Safety Data Sheets (SDS), or regulations applicable to your country and region.

- This product contains materials and components which may be recycled or reused according to local guidelines and regulations.
- Remove any batteries present before disposal. Batteries, battery packs, and accumulators should not be disposed of as unsorted household waste. Please use the public collection system to return, recycle, or treat them in compliance with the local regulations.
- Remove all samples and items before defrosting a unit to room ambient temperatures.
- Clean up any chemical or biological safety hazards using appropriate methods.
- Remove the cabinet door to help prevent entrapment inside of a unit.
- Have a certified technician remove the refrigerant and compressor, drain the compressor and oil from the system, and dispose properly. Note that oil may be infused with refrigerant and should be handled with care by someone experienced with refrigerants used in this product, as listed on the serial data plate.

Warranty

Domestic & International Warranty • 48 Months Parts and Labor, 5 years for compressor parts

During the first forty eight (48) months from shipment, Thermo Fisher Scientific Inc, through its authorized Dealer or service organizations, will at its option and expense repair or replace any part found to be non-conforming in material or workmanship. Thermo Fisher Scientific Inc reserves the right to use replacement parts, which are used or reconditioned. Replacement or repaired parts will be warranted for only the unexpired portion of the original warranty.

This warranty does not apply to damage caused by (i) accident, misuse, fire, flood or acts of God; (ii) failure to properly install, operate or maintain the products in accordance with the printed instructions provided, (iii) causes external to the products such as, but not limited to, power failure or electrical power surges, (iv) improper storage and handling of the products, (v) use of the products in combination with equipment or software not supplied by Thermo Fisher; or (vi) installation, maintenance, repair, service, relocation or alteration of the products by any person other than Thermo Fisher or its authorized representative. To obtain proper warranty service, you must contact the nearest authorized service center or Dealer. Thermo Fisher Scientific, Inc's own shipping records showing date of shipment shall be conclusive in establishing the warranty period. At Thermo Fisher's option, all nonconforming parts must be returned to Thermo Fisher postage paid and replacement parts are shipped FOB Thermo Fisher's location.

Limitation of Liability:

THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, WHETHER WRITTEN, ORAL, OR IMPLIED. NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE SHALL APPLY. THERMO FISHER DOES NOT WARRANT THAT THE PRODUCTS ARE ERROR-FREE OR WILL ACCOMPLISH ANY PARTICULAR RESULT.

THERMO FISHER SHALL NOT BE LIABLE FOR ANY INDIRECT OR CONSEQUENTIAL DAMAGES INCLUDING, WITHOUT IMITATION, DAMAGES TO LOST PROFITS OR LOSS OF PRODUCTS.

Regulatory Compliance

Product Safety

Product Testing

This product family has been tested to applicable product safety standards by a Nationally Recognized Test Laboratory (NRTL) and may bear the NRTL's mark of safety compliance to those applicable standards.



Hydrocarbon Refrigerants

This freezer employs natural hydrocarbon refrigerants. Because of the nature of hydrocarbon refrigerants, mechanical repair, such as recharge or compressor replacement, should only be carried out by a certified refrigeration technician.

Electromagnetic Compatibility

FCC Statement (USA)



This device complies with Part 15 Subpart B of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Canadian ISED IC Notice

This ISM device complies with Canadian ICES-001, Class A.

Cet appareil ISM est conforme à la norme NMB-001 du Canada, Classe A.

Energy Efficiency

ENERGY STAR



This product family has been voluntarily evaluated, and found compliant, by an EPA approved certification body to the EPA ENERGY STAR Laboratory Grade Refrigerators and Freezers Specification 1.1. This compliance is verified at $24.0\text{ }^{\circ}\text{C} \pm 1.0\text{ }^{\circ}\text{C}$ ($75.2\text{ }^{\circ}\text{F} \pm 1.8\text{ }^{\circ}\text{F}$), installed as described in this user manual, and in the default condition and settings of the product when shipped. Details can be found in the product Technical Specification Sheet or online at energystar.gov.

This page is
intentionally
left blank.

This page is
intentionally
left blank.

This page is
intentionally
left blank.



IF YOU NEED ASSISTANCE:

Thermo Fisher Scientific products are backed by a global technical support team ready to support your applications. We offer cold storage accessories, including remote alarms, temperature recorders, and validation services.

Visit www.thermofisher.com/cold or call:

Countries	Sales
North America	+1 866 984 3766
Taiwan	+852 2885 4613

Thermo Fisher Scientific (Asheville) LLC
275 Aiken Road
Asheville, NC 28804
United States

Find out more at thermofisher.com/cold

