# **Avery Weigh-Tronix**

# 7820 Parcel Shipping Scale

Ideal for busy, demanding parcel and shipping applications

Technical Specification



### DESCRIPTION

The 7820 durable 12" x 14" Bench Scale provides a fast accurate weight reading that fits into any operation as a stand-alone scale, interfaced to a shipping manifest software or receiving station.

Designed with a hard wearing stainless steel weight platter and a rugged aluminum die cast housing and load bridge that offers outstanding protect to the centrally mounted aluminum analog load cell.

Supplied with a built-in, flush-fitting, six digit ½" high LCD display that is mounted in the front face of the base.

An optional second remote display can be plugged in to give a customer facing weight reading.

A range of emulation protocols are available within the scale to allow you to quickly select the correct compatible communication protocol to interface with a wide range of third party post, mail and shipping software programs or host devices. This will be communicated through either a serial RS232, USB (HID) or USB (VCP) port found on the rear of the base.

## SPECIFICATIONS

#### COMMUNICATION

Connectivity

1 x RS232 (9 way female D Type connector ), 1 x USB HID (Mini USB) or 1 x USB VCP (USB-Type B) 1 x 2nd Remote display connection (RJ 45) *All are positioned on the rear of the base* 

**Supported Protocols** Standard NCI default with field configurable settings of 8213, 3835, SMA, with Auto Weight Send (2400 – 19.2K baud range) Transmits weight and scale status whenever ASCII "W" <CR> is sent by a remote device.

# 7820 PARCEL SHIPPING SCALE Technical Specification

#### **Display Type** Flush fitting six digit, 1/2" high LCD display Optional 2nd remote six digit, 1/2" high LCD display housed in an extruded enclosure with a 7 foot cable, connected via RJ 45 connector on the rear of the scale base Number of Displays Allowed 2 (1 standard, 1 remote display optional) **Display Bracket Options** Optional 12" high pole mounted display bracket **Remote Display Housing Sizes** 8" x 3" x 1.5" **Operational Keys** ZERO: Includes Auto Zero Tracking or Manual push button to re-establish zero reference TEST: Runs a diagnostic test to ensure scale is fully functional and allows a real-time view of internal settings Units of Measure Ib or kg (Ib default) **Incremental Selections** Multiples and sub-multiples of 1, 2, 5 **Configurable Selections** Capacity, resolution, filters, baud rates, protocols, auto printout, scale or post classifier Default configuration is as postal weight classifier **Time and Date** No **Base Sizes** 12" x 14" x 4.5" (305mm x 357mm 114mm) 14.1 3.6 8888 (. 35) (5, 4)--(2.6)-(10.4) (13.4) **Top Pan Construction** Stainless steel weight platter Optional: Ball top weight platter (9 balls) **Base Construction** Rugged with powder coated die cast aluminum housing and load bridge, housing a aluminum NTEP approved analog load cell Lockable adjustable feet, 1" diameter with up to 1" of height adjustment **Base Capacity** Capacity (lb) Capacity (kg) 100 lb x 0.02 lb 50 kg x 0.01 kg\* 150 lb x 0.05 lb 60 kg x 0.02 kg\* Lockable adjustable feet, 1" diameter with up to 1" of height adjustment 120 VAC (+10% -15%), 60 Hz, standard 3-wire ground Power **Operating Environment** Temperature: 42° F to 104° F (5° C to 40° C) Relative Humidity: 10 to 95% (non-condensing) Calibration 2 point calibration process (zero and span capacity) Field calibration can be carried out by using less than full capacity weights Gravity compensation to allow the local gravity to be entered for where the scale is to be used Internal Resolution 1 part in 120,000 Filtering Fast or Slow

Self-Diagnostics

DISPLAY

2 level diagnostics: front panel display test or full service diagnostics. (Display, RAM, ROM, input/output & high resolution x10 division test)

## Avery Weigh-Tronix

#### **OPTIONS**

Pole Mount

Ball Top Weight Platter

12" high pole indicator stand to allow easy viewing of the indicator

Stainless steel, using 9 roller balls to simplify handling and transport of all parcels. One piece lift-off design for easy field retrofitting



#### **APPROVALS**

Certifications

NTEP approved for use in Class III operations, CC 95-070 Canada Weights and Measures approval CC # AM-5076 Rev 4



Measurement Canada Approved AM-5076 Rev 4

## 7820 PARCEL SHIPPING SCALE Technical Specification



www.averyweigh-tronix.com

Avery Weigh-Tronix is an ITW company



Avery Weigh-Tronix is a trademark of the Illinois Tool Works group of companies whose ultimate parent company is Illinois Tool Works Inc ("Illinois Tool Works"). Copyright © 2016 Illinois Tool Works. All rights reserved. This publication is issued to provide outline information only and may not be regarded as a representation relating to the products or services concerned. This publication was correct at the time of going to print, however Avery Weigh-Tronix reserves the right to alter without notice the specification, design, price or conditions of supply of any product or service at any time.