

C3255

Checkweigher

CE



- **Capacity**– 15 kg / 30 lb, 30 kg / 60 lb, 60 kg / 150 lb, 150 kg / 300 lb
- **Stainless Steel Construction**– Wipe-down environment friendly
- **LCD Display**– Bright, large and visible
- **Power Options**– Battery and AC power
- **Preset Targets**– Includes 10 preset
- **Checkweighing Features**– Checkweighing bar graph, push button target setting, simple weight display, over/under/accept indicators, and audible alarm for target
- **Approvals**– NTEP

VALUE IN
WEIGHING

C3255 Checkweigher

Features

Display Type: 7 segment LCD with annunciators and bar graph. Large 1.2" digits.

Battery Operation: Uses 6 "C" cell batteries (not included) allowing remote operation and portability. The battery supports over 120 hours of continuous operation.

Ten Preset Targets: Allows quick selection of the items to be weighed. Setting new targets is quick and simple via the keyboard.

Unit Switching: Accessed through the "mode" key. Either lbs, kg or oz may be selected.

Count Function: A simple and accurate feature is available under the "mode" switch

Target Graph: In the checkweigher mode the graph indicates over, under or accept with a full visual representation of the weight in relation to the target

Folding Column: The display unit folds down for storage and shipping

Selectable Calibration Settings: Choose from full, 1/2, and 1/4 capacity

Key Functions: On/off, mode, net/gross, zero, tare, call, 0-9



Model C3255 Battery Compartment

Specifications

Capacity / Resolution (NTEP)

nmax	lb	nmax	kg	nmax	oz
6000	12 x 0.002 lb	6000	6 x 0.001 kg	3840	192 x 0.05 oz
6000	30 x 0.005 lb	6000	12 x 0.002 kg	4800	480 x 0.1 oz
6000	60 x 0.01 lb	6000	30 x 0.005 kg	4800	960 x 0.2 oz
6000	120 x 0.02 lb	6000	60 x 0.01 kg	3840	1920 x 0.5 oz
6000	300 x 0.05 lb	6000	120 x 0.02 kg	4800	4800 x 1 oz
3000	15 x 0.005 lb	3000	6 x 0.002 kg	2400	240 x 0.1 oz
3000	30 x 0.01 lb	3000	15 x 0.005 kg	2400	480 x 0.2 oz
3000	60 x 0.02 lb	3000	30 x 0.01 kg	1920	960 x 0.5 oz
3000	150 x 0.05 lb	3000	60 x 0.02 kg	2400	2400 x 1 oz

Scale Dimensions:

483 mm (H) x 343 mm (W) x 502 mm (D)
19" H x 13.5" W x 19.75" D

Platter Dimension:

342 mm (W) 442 mm (D)
13.5" W x 17.4" D

Operating Temperature: 5° C - 35° C / 41° F - 95° F

Power Supply: 15V, 300mA, US AC adapter (included)

Packaging Dimension:

660 mm (L) x 508 mm (W) x 305 mm (H)
26" L x 20" W x 12" H

Shipping Weight: 15 kg / 33 lb

Certifications: CE, NTEP CC# 04-088,

Full FCC compliance, UL/CUL power adapter

Product Code:

816965000746: 30 lb

816965000753: 60 lb

816965000760: 150 lb

816965000777: 300 lb



a division of Avery Weigh-Tronix, LLC

Brecknell

1000 Armstrong Dr., Fairmont, MN 56031
Toll free: 800-637-0529, Tel: 507-238-8702
Fax: 507-238-8271
e-mail: sales@brecknellscales.com
www.brecknellscales.com



Brecknell

Foundry Lane, Smethwick
West Midlands B66 2LP UK
Tel: +44 (0) 845 246 6717
Fax: +44 (0) 845 246 6718
Email: sales@brecknellscales.co.uk
www.brecknellscales.co.uk

