

# LPS400

## Portable Shipping Scale CE



- **Accuracy**– 0.1% of full scale
- **Capacity**– 182 kg / 400 lb
- **Construction**– Low profile stainless steel platform with mild steel understructure, and stainless steel/ABS indicator with wall bracket and desk mount included.
- **Platform Dimension**–  
380 mm (L) x 305 mm (W) x 27 mm (H)  
15" W x 12" L x 1" H
- **Protocol**– Standard NCI interfaces to most common shipping software, including UPS™ Worldship Online.  
Not legal for trade
- **Display**– Five 16 mm / 0.625" digits LCD
- **Power**– Battery
- **Operator Keys**– On/Off/Zero, Tare, Units (lb/kg), Hold/Print

VALUE IN  
WEIGHING

# LPS400 Portable Shipping Scale

## Features

LPS400 scales are particularly suited to shipping and warehouse applications and general purpose weighing. These are very affordable scales with high accuracy.

A large, simple to read display can be wall or stand mounted for easy visibility and the large keyboard switches work with gloved hands (wall and desk bracket included).

The indicator cable is a coil style for durability and easy extension.

The LPS400 features RS-232 interface that can transmit and receive using a demand type protocol.

Scale comes standard with NCI protocol and interfaces to most common shipping software, including UPS™ Worldship Online.

A durable low profile platform allows for easy weighing. The LPS400 is a low cost yet versatile and portable scale.

- Application
- Shipping/Receiving
  - Mailroom
  - Manifest Systems
  - General Purpose Weighing

Not legal for trade



a division of Avery Weigh-Tronix, LLC

### Brecknell

1000 Armstrong Dr., Fairmont, MN 56031  
Toll free: 800-637-0529, Tel: 507-238-8702  
Fax: 507-238-8271  
e-mail: sales@brecknellscales.com  
www.brecknellscales.com



### Brecknell

Foundry Lane, Smethwick  
West Midlands B66 2LP UK  
Tel: +44 (0) 845 246 6717  
Fax: +44 (0) 845 246 6718  
Email: sales@brecknellscales.co.uk  
www.brecknellscales.co.uk



## Specifications

### Capacity:

182 kg x 0.1 kg / 400 lb x 0.2 lb / 400 lb x 5 oz

### Platform Dimension:

380 mm (L) x 305 mm (W) x 27 mm (H)  
15" W x 12" L x 1" H

### Indicator:

164 mm (L) x 81 mm (H) x 29 mm (W)  
6.5" L x 3.2" H x 1.2" W

### Display:

Five 16 mm / 0.625" digits LCD



**RS-232:** 10' interface cable (DB-9) (included)

**Keyboard:** On/Off/Zero, Tare, Units (kg/lb), Hold/Print

**Units:** lb, kg, lb/oz

**Power:** Four AAA batteries (included)

**Battery Life:** 20 hours

**Operating Temperature:** 5° C to 35° C / 41° F to 95° F

### Packaging Dimension:

Scale: 450 mm (L) x 400 mm (W) x 60 mm (H)  
17" L x 15" W x 2.3" H

**Shipping Weight:** 5 kg / 11 lb

**Certifications:** CE

**Product Code:** 816965006182