MAILING/SHIPPING SCALES



MODEL	CAPACITY	PLATFORM SIZE	
MS-8	8 lb x 0.1 oz	10" W x 8.25" D /	
		25 cm W x 21 cm D	

Display: 5-digit, 0.6" (15mm) high red LED with weight and rate

status indicators

Power: 115 VAC +/- 10% 60 Hz **Shipping Weight:** 11 lb / 5 kg

FEATURES

- Selectable default service (hold desired default key down when powered on)
- Rate mark-up
- Count feature
- Automatic zip-to-zone conversion
- Color-coded keys
- Weigh/rate display
- Envelope stand to allow large envelopes or packets to be processed

MS-8 Electronic "Mail-Master" Scale

Weigh, rate and count your mail accurately with Detecto's MS-8 "Mail-Master"! The "Mail-Master" is a power-packed, auto rate calculating, 8 lb capacity scale designed for long-lasting performance and utilizing heavy metal construction and a large, brilliant red LED display. Value added features include letter counting and a selectable default service setting for maximum operational speed. A wide range of postal

rates are supported such as presort, international and express mail as well as many special services.



Cert. No. 94-066

The highly-visible, red LED display provides instant display

of weight, postage rate and numeric operator input such as zip/zone, country code and so forth. The interactive keyboard provides instant indication when a service is selected. "Sleep Mode" may be enabled to automatically turn off the display after ten minutes of non-use.

USPS SERVICES SUPPORTED

- 1st Class/Priority
- Standard mail
- Presorted/Basic automated
- International (air/surface, letter, parcel or printed matter)
- Certified
- COD
- Express mail post office to addressee
- Bound printed matter
- Insurance
- · Registered with insurance
- Return receipt

MSB-25 Bulk Mail Scale

Detecto's MSB-25 bulk mail scale can display weight of a single mailpiece, the number of pieces per pound, or the number of pieces on the scale after entry of a sample, making it a versatile scale for the mailroom or shipping department. Status indicators are included for motion, zero, gross weight, net weight, tare, weight per piece, piece per weight, count, sample, pounds, and pounds-ounces. You can use the rearmounted serial data interface for connection to an optional printer or computer for output of displayed information. A pullout card is attached underneath the front of the MSB-25 with operating instructions that are readily visible.

FEATURES

- Stainless steel weighing platform
- Simple keyboard calibration can be performed in minutes
- Display count, piece weight, or pieces per pounds
- 17" W x 21" D x 5" H / 43 cm W x 53 cm D x 13 cm H dimensions



 MODEL
 CAPACITY
 PLATFORM SIZE

 MSB-25
 25 lb x 0.005 lb or 0.1 oz
 17.5" W x 15" D / 44 cm W x 38 cm D

Display: Easy-to-read dot matrix **Power:** 110/120 VAC, 60 Hz **Shipping Weight:** 28 lb / 13 kg

MAILING/SHIPPING SCALES

VERSATILE AND ECONOMICAL

LOADED WITH CAPABILITIES



Cert. No. 91-163 Models MS-15, MS-30, and MS-100



MS-15/30/100/1600 Postal/UPS Scales

Now you can have a full range of capabilities in a scale that meets your budget, making parcel control affordable. The MS Series comes in a variety of capacities listed below to suit your needs. Detecto's MS Series Shipping Scales fully support all USPS and UPS services, provide zip-to-zone conversion, and manual weight entry. With a color-coded numeric keypad that's easy to use and to clean, these units also feature an easily replaceable rate cartridge. Calculations and zone charts are a thing of the past, just push a button and let Detecto do the work for you!

MODEL	CAPACITY	
MS-15	15 lb x 0.05 oz	
MS-30	30 lb x 0.1 oz	
MS-100	100 lb x 0.2 oz	
MS-1600	100 lb x 0.1 oz	Not "Legal-For-Trade"

Platform Size: 15"W x 9"D / 38 cm W x 23 cm D

Display: 0.5" (13mm) high LED display **Power:** 110/115 VAC, 50/60 Hz **Shipping Weight:** 21 lb / 10 kg

FEATURES

- Fully supported USPS and UPS services
- Zip-to-zone conversion
- Manual weight entry
- Full, color-coded numeric keypad
- Easily replaceable rate cartridge

USPS SERVICES SUPPORTED

- 1st Class / Priority
- Standard
- Express Mail PO PO
- Express Mail PO Addressee
- 1st Class Presort / Zip + 4
- Bound Printed Matter
- Special Standard
- Special Delivery
- Registered
- International Surface
- International Air
- Insurance
- COD
- Library
- Certified
- Return Receipt

UPS SERVICES SUPPORTED

- Ground
- 2nd Day Air
- Next Day Air
- 3rd Day Select
- Delivery Confirmation Response
- COD
- International
- Oversize Packages
- Declared Value
- Dimensional Weight

MODEL	USE IN LEGAL FOR TRADE APPLICATION	FIRST CLASS MAIL	INTERNATIONAL AIR MAIL
MS-15	Yes	Yes	Yes
MS-30	Yes	Yes	Yes, over 1 oz
MS-100	Yes	Yes, 2 oz or more	Recommend MS-15/MS-30
MS-1600	No	Yes	Yes