





Utility and economy come together in the ES Series of all-purpose bench scales. The low profile design of the ES Series scales makes them perfect for shipping, receiving, and general bench applications. Easy, twobutton operation and a large display help guarantee accurate and unmistakable results. The unique threeway mounting bracket allows you to mount the indicator to the scale base, above the scale platform, or on any vertical surface. For simple weighing at a favorable cost, the ES Series is the scale to choose.

Standard Features Include:

- 6 Models to choose from: 13.2 lb to 440 lb (6 kg to 200 kg)
- Features kg, lb, oz and lb:oz units
- Simple two-button operation
- Battery or AC power (adapter included)

ES Series Low Profile Bench Scales

Specifications

opcontrolla							
Maximum Displayed Readability	kg	6 x 0.002	30 x 0.01	50 x 0.02	50 x 0.02	100 x 0.05	200 x 0.1
	lb	13.225 x 0.005	66.1 x 0.05	110.2 x 0.05	110.2 x 0.05	220.4 x 0.1	440.8 x 0.2
	0Z	211.6 x 0.1	1,058.0 x 0.5	1,763 x 1.0	1,763 x 1.0	3,526 x 2.0	7,050 x 5.0
	lb:oz	13:3 x 1 oz	66:2 x 1 oz	110:3 x 1 oz	110:3 x 1 oz	220:6 x 2 oz	N/A
Weighing Units		kg, lb, oz, lb:oz kg, lb,					
Display	(in/cm)	1 inch / 2.54 cm digit height LCD					
Display Indicators		Weighing unit, stability, overload, underload					
Keyboard		Two function membrane switches					
Tare Range		To capacity by subtraction					
Stabilization Time		Within 3 seconds					
Overload Capacity		150% of capacity					
AC Power		9VDC AC wall adapter (included)					
Battery		6 "AA" (not included) batteries with 30 hours continuous use					
Span Calibration		100%			50 %		
Operating Temperature		14° F to 104 ° F / -10° C to 40° C					
Storage Temperature		14° F to 158° F / -10° C to 70° C					
Base Size	(in/cm)	12.2 x 10.8 x 1.5 / 31 x 27 x 4			20.5 x 15.7 x 3 / 52 x 40 x 7.5		
Indicator Stand	(in/cm)	4 / 10 high above pan					
Shipping Dimensions (in/cm)		13 x 15 x 5.5 / 32 x 37 x 14			19 x 24 x 9 / 48 x 60 x 23		
Net Weight	(lb/kg)	6.6 / 3			33 / 15		
Shipping Weight	(lb/kg)	8.8 / 4			38 / 17		
Item Number		ES6R	ES30R	ES50R	ES50L	ES100L	ES200L

Standard Features

Stainless steel pan, painted steel frame, easy two-button operation, stability indicator, auto-zero tracking, overload indicator, underload indicator, low power indicator, battery saving auto-off timer (power off after 5 minutes of inactivity), selectable averaging speed, three-way mounting bracket (mounts indicator to base, above base, or to wall), AC power adapter, large ("L") platforms feature leveling feet.

Approvals

Meets Requirements of Approval Agencies: UL, FCC, CSA, CE Safety EN60950, Emissions EN55022, Immunity EN50082-1.

Industry Leading Quality and Support

All OHAUS ES Series Bench Scales are manufactured under an ISO 9001:2000 Registered Quality Management System. Our rugged construction and stringent quality control have been hallmarks of all OHAUS products for over a century.

Ohaus Corporation

* 19A Chapin Road P.O. Box 2033 Pine Brook, NJ 07058 USA

Tel: 800.672.7722 973.377.9000 Fax: 973.593.0359

www.ohaus.com

With offices throughout Europe, Asia, and Latin America

* ISO 9001 Registered Quality Management System

© Copyright OHAUS Corporation

80774392

