FAIRBANKS® ΩMEGA COUNTING SCALE

• KITTING

• ACCUMULATION

• PARTS COUNTING

Cost-effective, high-performance scale for infinite counting apps!

Piece Weight 5 6 Piece 2 3 OCS-15 Max=15lb d=0.0005l

• GENERAL WEIGHING

Visit our world today: Fairbanks.com



Ω MEGA COUNTING SCALE

1,000,000 Internal Counts Bar Code Scanning

ne, two, three, four...still counting parts by hand? Why? Eliminate this mind-numbing task, greatly reduce material handling time and increase accuracy with the Omega Counting Scale. Designed for warehousing and light manufacturing applications, this scale will deliver reliable, easy and fast counting

functions sure to increase efficiency and reduce overhead. The Omega's ability to store hundreds of parts in memory (PLU) further reduces time spent counting. Parts warehouses and production companies will find the Omega an invaluable tool for accurately maintaining inventories of small or large components.

Features

- Internal resolution of 1,000,000 counts
- Displayed resolution 30,000d
- Auto-resampling
- Four sampling methods
- Simultaneous weight display weight, pieces, piece weight
- Net/Gross weight display
- Two RS232 outputs
- AC and/or lead acid rechargeable battery
- Auto sleep timer

Applications

Weighing, counting, checkweighing, checkcounting or kitting, the Omega Counting Scale is a cost-effective, high-performance scale designed for a full-range of weighing applications.

• 999 parts look up (PLU)

- Remote scale interface (standard)
- · Hi/Lo weighing and parts counting
- Audible beep operation
- 36 button keypad
- Accumulation weight and piece count
- Bar code reader (tare, PLU and piece weight) sold separately
- User-selectable printing (bar code printing optional)
- Time and date

The Omega's large, stainless steel platform can easily accommodate most product storage bins. This scale is ideal for quarterly/semiannual inventories and parts counting applications.



Remote Scale Interface Stainless Steel Weigh Pan Internal Life-Long Battery Automatically Minimizes Errors

www.fairbanks.com

FUNCTIONS 36-button Keypad makes operations quick and easy — No toggling required!



FAIRBANKS Ω MEGA **COUNTING SCALE**



SPECIFICATIONS

Capacities	11
Displayed resolution 30,000d (100 lb = 50,000d)	- 18
Units Pounds and kilograms/grams	
Display	
TypeBacklit LCD	Tł
Character height 0.57" tall,	or
Lines (3) Weight - 6 characters;	Se
Piece weight - 7 characters;	of
Pieces - 7 characters	
Internal resolution 1,000,000	
Operating temperature 32° F to 104° F	
Relative humidity < 85%	
Memory	
Remote scale interface Four 350 ohm load cells, 2 mV/V max	
Interface Serial 1 RS232 for printer, computer	
or remote display;	
Serial 2 RS232 for bar code reader only	
Power AC adapter	
Input - 120 VAC 60 Hz 0.15A	
Output - 9 VAC 500 mA	
BatteryBuilt-in rechargeable, 6V lead acid	
Battery life 15 to 20 hours continuous (local platform	only)
Battery recharge time 14 to 16 hours	
Approval UL	
(^w L)	



The Omega's backlit LCD display is extremely easy to see in low or bright light conditions. The display also features programmable ettings that conserve power consumption, increasing the lifespan of the scale's internal rechargeable battery.



ACCESSORIES





2844 Printer



Call toll-free for the representative nearest you:

(800) 451-4107

Call between 8:00 a.m. - 5:00 p.m. Central Time Corporate Offices: 821 Locust · Kansas City, MO 64106 · (816) 471-0231 www.Fairbanks.com Models and specifications subject to change without notice. © Fairbanks Scales Inc.

